

ASS Anschraubklemme Endstück ASS End Stop for ASS Attaching clip

Das Endstück der ASS Anschraubklemme wird in Kombination mit der ASS Anschraubklemme eingesetzt und an beiden Seilenden als Endbeschlag benötigt.

Das Endstück hat eine Bohrung, um den Seilendbeschlag, i. d. R. ein ASS Super-Mini Gewindeterminale aufzunehmen. Die Aussenkante des Endstückes weist eine Abflachung auf, die stets zur Mutter bzw. zur Kugel gerichtet wird.

Bitte verwenden Sie in Verbindung mit dem Endstück die kleine Ausführung unserer ASS Kugel. Bitte montieren Sie die ASS Kugel immer an der schmalen Fläche des Endstücks. Die technischen Daten der ASS Kugel finden Sie auf der Seite 5.0.3 in diesem Katalog.

Montage siehe unten

The ASS End Stop for the ASS Attaching clip is used in combination with the ASS Attaching clip. There is one end stop required for each rope end.

The ASS End Stop shows a bore hole to carry the end fitting of the rope, usually an ASS Threaded terminal, Super-Mini type. The outer edge of the end stop is equipped with a flat part which should be directed to the lock nut or ball.

Please use the small type ASS Ball in connection with the ASS End Stop for ASS Attaching clip. Always assemble the ASS Ball on the narrow side of the ASS End Stop. All technical details for the ASS Ball are given in this catalogue on page 5.0.3.

Assembly see pictures below

